




**Wilkins 720A**  
**Backflow**  
**Hunt Irrigation, Inc.**  
 2600 West "L" Street  
 Suite A  
 Lincoln, NE 68522  
**Phone: 402-438-8151**

## Freeze Protection Guidelines

1. Go to basement (Utility Room)
2. Close main shut-off valve (Ball Valve w/ handle)
3. Open interior drain (Boiler drain w/ Tee Handle or Knob)
4. Locate vacuum breaker on the exterior of the house
5. Open test cocks **A** and **B** w/ a 1/2" combination wrench (Look on diagram)
6. Leave test cocks and interior drain open all winter
7. Turn **Blue Handles** at a 45° angle to prevent freezing
8. Turn controller to the off position
9. ☐ If box is checked you have a master valve:  
 Cycle controller through one manual cycle  
 and then turn controller to the off position
10. \*Be sure to check interior drain a week  
 after winterization if water  
 continues to drain out  
 call for service immediately



## Spring Pressurization Guidelines

1. Locate vacuum breaker on the outside of the house
2. Close test cocks **A** and **B** w/straight screwdriver
3. Move **Blue Handles** from the 45° position to the fully open position
4. Turn controller on & activate Zone 1
5. Go to basement & close interior drain
6. Open shut-off valve (SLOWLY)
7. Listen for vacuum breaker to seal  
 (There will be a light to moderate hammering)
8. Turn controller off
9. Inspect yard & backflow  
 for any leaks.
10. Program controller for Spring  
 schedule

